

Direct-Write Patterning of Marker-Free Nano Devices

Onri Jay Benally


University of Minnesota

Department of Electrical & Computer Engineering

Principal Investigator: Prof. Jian-Ping Wang

Table of Contents


- I. Background & Motivation.
- II. Electron-Beam Lithography Overview.
- III. Equipment Limitations.
- IV. Design Process Flow.
- V. Device Results.
- VI. Examples of Alternative E-Beam Resist.
- VII. Conclusion.




Crippa et al., *Phys. Rev. Lett.* (2018)

Background & Motivation


- Conventional optical lithography = **ultraviolet photon** exposure.
- Electron beam lithography = **electron** beam exposure.
- Ultimately, the *wavelength* of the energy being applied to a resist coating determines the feature size.
- It's possible to obtain 3-5 nm resolution with electron-beam lithography
 - Depends on your skill level (abstract).



**Maskless Ultraviolet
Lithography**






**Maskless Extreme
Ultraviolet
Lithography**



**Maskless Electron
Beam Lithography**


1. Venturi, *PhD Thesis* (2017)
2. Taken from: thumbs.gfyc.com
3. Taken from: *Wikimedia Commons*

Basic Principle of Electron-Beam Exposed Features



Typical Markers Used in E-Beam

What makes a good alignment mark?



Marks are usually squares, 4 to 20 μm on a side.
Etched holes should be $\leq 5 \mu\text{m}$ wide.
Crosses can also be used, compatible with JEOL

Equipment Advantages & Disadvantages



- Advantages:

- Relatively high-resolution lithography.
- Maskless procedure allows for indirectly importing AutoCAD drawings.
- Fast design modification.
- Vacuum environment leads to better control of contamination.
- Markers can be avoided


- Disadvantages:

- Vacuum environment required.
- Charge build-up, even during SEM inspection.
- Low throughput.
- Proximity effects.

Equipment Advantages & Disadvantages





VS.



Design Process Flow


- Design file conversion is a bit extensive.

• CAD **DWG** → **DXF** → **GDS II** → Beamer → **GPF** → **CJOB** → **JOB File**



Additional
Parameters
(dosage, sub. size,
etc.)

During final setup,
machine actually
uses this one.







Terminal

Maskless Direct Writing Using “Joyplus”

- Doses:
 - For relatively larger features (**pads & stripes**): $450 \mu\text{C}/\text{cm}^2$.
 - For smaller features (**pillars**): $825\text{-}875 \mu\text{C}/\text{cm}^2$.

- Basically:



- Locate 4 Points → SEM-Aided ‘Marker’ Location → Record Final Marker Position → **Confirm & Write!**



Basic Flow Summary of “Joyplus” for E-Beam



- Enter relative coordinates >> locate desired marker reference points >> record real coordinates found >> enter (pg move position) of real coordinates >> type (joyplus) >> confirm real coordinates of marker locations by inspecting SEM scan >> press Enter.
- You may now continue with job file locations and other parameters for stage selection >> copy-paste job command into terminal >> press Enter >> watch 1st few steps of exposure >> Done!

Randomized Example of Standard Fabrication Flow





*PR = Photoresist ***EBR = Electron-Beam Resist
** Ω = Resistance



Nano Magnetic Tunnel Junction Results





Nano Magnetic Tunnel Junction Results




Nano Magnetic Tunnel Junction Results




Nano Magnetic Tunnel Junction Results



Magnetic Device Rendering Results



Double Squares Array Success (No Markers)



Green Lithography Methods

Table 1. The cost comparison among egg white, silk protein, organic and polymer resists

Type	Material	Source	Cost
EBL positive resist	Poly(methyl methacrylate)	EM Resist Ltd. ^{a)}	1.49 [\$ mL ⁻¹]
EBL negative resist	Hydrogen silsesquioxane	Meryer Chemical Technology ^{b)}	25.17 [\$ g ⁻¹]
UV positive resist	2,3,4-Trihydroxybenzophenone	Sigma-Aldrich	3.68 [\$ g ⁻¹]
UV negative resist	Poly(vinyl cinnamate)	Sigma-Aldrich	45.88 [\$ g ⁻¹]
Silk resist	Fibroin silk solution	Advanced BioMatrix ^{c)}	12.75 [\$ mL ⁻¹]
Egg white resist	Egg white solution	Local Supermarket	0.37 [¢ mL ⁻¹]
	Glycerol	Sigma-Aldrich	0.45 [\$ mL ⁻¹]




a) <http://www.emresist.com/webshop/pmma-product-details.php>

b) <http://www.meryer.com/cn/products/detail.aspx?ProID=19970>






c) [https://www.advancedbiomatrix.com/fibroin-silk-solution-2/fibroin-silk-solution/?gclid = CPr09dDGqdACFZclvQodcVcKEA](https://www.advancedbiomatrix.com/fibroin-silk-solution-2/fibroin-silk-solution/?gclid=CPr09dDGqdACFZclvQodcVcKEA).

***Resolution limit was verified at 15 nm.**

Green Lithography Methods



Green Lithography Methods



***Alternative name for egg white resist: albumen**

Summary

- Electron-beam lithography can provide **repeatable/modifiable design steps**.
- The stage setup can be taped to **reduce charge build up**.
- Operation of design can be **automated** with Python code if needed in Beamer.
- **Green lithography** can be used to reduce cost as an experimental electron-beam resist.
- A repository will be made available on **marker-free** electron-beam patterning.